

FIRE ESCAPE PLAN

Abbey Church 21, Third floor



LOCH NESS



THE HIGHLAND CLUB
FORT AUGUSTUS • LOCH NESS

If you discover a **fire** or hear the **fire alarm** please leave the building **immediately** without collecting belongings and raise the alarm by pressing the call point.

Follow the **green signs** to the **fire exit** and go down the stairs to exit and **assembly point**, once outside please call **999** and wait for further instructions from staff.